


Remote I/O R5 Series

THERMOCOUPLE INPUT MODULE

(re-transmitted output)



MODEL: R5-TS1A[1]

ORDERING INFORMATION

• Code number: R5-TS1A[1]

Specify a code from below for [1]

(e.g. R5-TS1AW)

NO. OF CHANNELS

1: 1 channel

OUTPUT

Current

A: 4 – 20 mA DC (Load resistance 600 Ω max.)

[1] COMMUNICATION MODE

S: Single

W: Dual

GENERAL SPECIFICATIONS

Connection

Internal bus: Via the Installation Base

(model: R5-BSx)

I/O: Euro type connector terminal

Wire size AWG24-12 (0.2 – 2.5 mm²)

Power supply: Via the base (model: R5-BSx)

Isolation: Input to output to internal power

Zero/Span adj. mode selector: Rotary switch; monitor mode, adj. mode and simulated output mode selectable

Sensor type: Selectable with the side DIP SW

Temperature unit: °C, °F or absolute temperature selectable with the side DIP SW

Burnout detection: Upscale or downscale selectable with the side DIP SW

Linearization: Standard

Cold junction compensation: CJC sensor attached to the input terminals

RUN indicator: Bi-color (red/green) LED;

Red when the bus A operates normally;

Green when the bus B operates normally;

Amber when both buses operate normally.

INPUT SPECIFICATIONS

Input resistance: 30 kΩ min.

Burnout sensing: ≤ 0.1 μA

Temperature range

T/C	°C	
	USABLE RANGE	CONFORMANCE RANGE
K (CA) (*) ^{*1}	-272 to +1472	-150 to +1370
E (CRC) ^{*1}	-272 to +1120	-170 to +1000
J (IC)	-260 to +1300	-180 to +1200
T (CC) ^{*1}	-272 to +500	-170 to +400
B (RH) ^{*1}	24 to 1920	400 to 1760
R	-100 to +1860	200 to 1760
S	-100 to +1860	0 to 1760
C (WRe 5-26)	-52 to +2416	0 to 2315
N ^{*1}	-272 to +1400	-130 to +1300
U	-252 to +700	-200 to +600
L	-252 to +1000	-200 to +900
P (Platinel II)	-52 to +1496	0 to 1395
(PR)	-52 to +1860	0 to 1760

T/C	°F	
	USABLE RANGE	CONFORMANCE RANGE
K (CA) ^{*1}	-458 to +2682	-238 to +2498
E (CRC) ^{*1}	-458 to +2048	-274 to +1832
J (IC)	-436 to +2372	-292 to +2192
T (CC) ^{*1}	-458 to +932	-274 to +752
B (RH) ^{*1}	75 to 3488	752 to 3200
R	-148 to +3380	392 to 3200
S	-148 to +3380	32 to 3200
C (WRe 5-26)	-62 to +4381	32 to 4199
N ^{*1}	-458 to +2552	-202 to +2372
U	-422 to +1292	-328 to +1112
L	-422 to +1832	-328 to +1652
P (Platinel II)	-62 to +2725	32 to 2543
(PR)	-62 to +3380	32 to 3200

(*) Factory setting. Set the input range within 0-1000°C corresponding to the output range 0-10000.

^{*1} Accuracy degrades at temperatures close to the lower limit of the usable range.

Max. (upscale) or min. (downscale) value of the usable range when a burnout is detected.

OUTPUT SPECIFICATIONS

Operational range: Approx. 0 – 24 mA DC

INSTALLATION

Operating temperature: -10 to +55°C (14 to 131°F)
Operating humidity: 30 to 90 %RH (non-condensing)
Atmosphere: No corrosive gas or heavy dust
Mounting: Installation Base (model: R5-BSx)
Weight: 100 g (3.53 oz)

PERFORMANCE

Conversion accuracy

Input: $\pm 0.4^{\circ}\text{C}$ ($\pm 0.6^{\circ}\text{C}$ for C thermocouple)

Output: ± 0.1 % of the retransmitted range + input conversion accuracy (May exceed ± 0.1 % depending upon the input temperature range.)

Conversion data: Temperature data scaled and converted into 0 – 100 % data and supplied to the internal network bus

Data allocation: 1

Cold junction compensation error: $\pm 0.5^{\circ}\text{C}$ or $\pm 0.9^{\circ}\text{F}$
(at $20^{\circ}\text{C} \pm 10^{\circ}\text{C}$ or $68^{\circ}\text{F} \pm 18^{\circ}\text{F}$)

Temp. coefficient

Input: ± 0.015 %/ $^{\circ}\text{C}$ (± 0.008 %/ $^{\circ}\text{F}$)

Output: ± 0.02 %/ $^{\circ}\text{C}$ (± 0.01 %/ $^{\circ}\text{F}$)

Response time: ≤ 0.4 sec. (0 – 90 %)

Burnout response time: ≤ 2 sec.

Insulation resistance: ≥ 100 M Ω with 500 V DC

Dielectric strength: 1500 V AC @ 1 minute (input to output to internal power)

2000 V AC @ 1 minute (power input to FG; isolated on the power supply module)

STANDARDS & APPROVALS

CE conformity:

EMC Directive (2004/108/EC)

EMI EN 61000-6-4: 2007

EMS EN 61000-6-2: 2005

FUNCTIONS

• Zero/Span Adjustment Modes

Monitor Mode

Re-transmits the input signal as output in proportion.

Output 0 % Adjustment Mode

Adjusts the 0 % output signal using the front UP/DOWN buttons, in monitoring the output value with a multimeter. SW1 through SW3 switch the internal increments by 1, 5 and 10.

Output 100 % Adjustment Mode

Adjusts the 100 % output signal using the front UP/DOWN buttons, in monitoring the output value with a multimeter. SW4 through SW6 switch the internal increments by 1, 5 and 10.

Simulated Output Mode


Outputs the simulated signals of 0 %, 50 % and 100 %.

• How to Operate


- 1) Start up in Monitor Mode (SW position = 0) and wait for 2 or 3 seconds.
- 2) Switch to another mode and go through the adjustments.
- 3) Reset the switch to the position '0' so that the new setting is stored in the internal memory.

EXTERNAL VIEW


■ SIDE VIEW




■ FRONT VIEW



EXTERNAL DIMENSIONS & TERMINAL ASSIGNMENTS unit: mm (inch)



SCHEMATIC CIRCUITRY & CONNECTION DIAGRAM



*For dual redundant communication.



Specifications are subject to change without notice.